



FORTRESS


STABILIZATION SYSTEMS

Kit 6275—INSTALLATION SHEET




This product is intended to accompany a typical crack filling procedure. This kit includes only enough epoxy for attaching the repair straps. The crack injection must be fully cured before using this product.

LAYING OUT THE JOB/ PREPARING THE WALL




Step 1 Measure the length of cracks and divide the length into 2 ft. segments.

IMPORTANT: There must be no more than 24" between segments.



Step 2 Make sure that no obstructions interfere with the planned strap locations. Mark the location.



Step 3 Hold staple over the determined location at the appropriate angle and mark.

See the included guidelines to help determine the correct orientation of each staple according to angle and nature of the crack.




CAUTION: Carbon Staples can shed very fine splinters. Use gloves at all times when handling staples.

NextStar technologies
Suite 1095 /3 9899 112 Ave
Grande Prairie Alberta Canada T8V7T2 1-866-445-3984
U.S. Patents Pending


Visit us at:

www.NextStar.ca


Item No. 6275-1008 Printed in U.S.A.



Step 4 Use the Wall Slotter to cut a groove 1/4" deep where the staple is to be applied.



— If you don't have a wall slotter to inset the staple, mount a 3" chisel and prepare the concrete surface around the crack and where the staple will attach.




Step 6 Mount a 1/2" dia. masonry drill and make a hole 1" deep at each mark.

APPLYING THE REINFORCING STAPLE


For proper adhesion, the wall surface within this space must be **FREE OF PAINT** and as smooth as possible. Use a grinder to remove all bumps and irregularities in the wall, as well as any surface latency in the epoxy area.

NOTE: This area must also be cleaned free of all dust before you can proceed.




Step 1 Load the double-cylinder epoxy cartridge into the Jake applicator and "burp" the cartridge so that an even flow of material exits both cylinders. Then fasten the Static Mixing Tube to the end of the applicator. The epoxy will mix to a uniform green color.


Tip: The warmer the epoxy adhesive is, the faster it will set. You can save setting time by warming the epoxy. Do not exceed 120 °F.




Step 2 Fill the two holes and apply a coat of epoxy between them. Put on as much adhesive as needed to make a smooth, flat, layer 1/8" thick.



Step 3 Wearing protective gloves, position the staple over the two holes.



Step 4 Push the staple into the epoxy until it touches the wall.



Step 6 . Use the trowel to push epoxy to fill gaps and unfilled spaces. staple must be completely covered with epoxy when finished.

FORTRESS
STABILIZATION SYSTEMS

NextStar technologies
Suite 1095 /3 9899 112 Ave
Grande Prairie Alberta Canada T8V7T2 1-866-445-3984

U.S. Patents Pending

WWW.NextStar.ca

Carbon Fiber Installation with standard grinder and diamond Turbo cutting blade.

You will need:

Grinder with a 4.5 to 5 in segmented blade, Vacuum, Safety glasses and maybe dust protection.



1. Mark and ½ in drill holes for staples using a staple to trace out.



2. Using Grinder cut 3 slots 1/8- ¼ in deep between the holes.



3. Completed holes and slots cut



4. Knock out cement between slots and using grinder to remove any areas that are sticking out.



5. Vacuum out area and all dust in holes



6. Place staple into slot to make sure that it fits flat to the wall



7. Install Staple per regular instructions



Complete crack injection repair with Epoxy or Structural foam within 24 hrs before or after staple installation. It is usually best to install the staples first, let cure for approx 4 hrs, then complete crack injection.